COOKTOP PARTS

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)

30" ELECTRIC CERAN
FREESTANDING RANGE
SELF CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
1		Literature
	9762182	Instructions, Installation Template, Anti−Tip
	9757142	English/Spanish
	9757143	English/French
	9763040	Owners Manual
		Tech Sheet
	9762994	English
	W10041700	French
		Tips,Safer Cooking
	9762761	English
	9759133	French

Illus. No.	Part No.	DESCRIPTION
2	3149191	Spring, Locator
3	3196170	Screw
4		Cooktop
	9763330	White
	9763332	Black
5	9758893	Heat Shield

Illus. No.	Part No.	DESCRIPTION
7		Element, Surface
	9759351	2400/1200W − LF,RF
	8523698	1200 W − LR,RR
9	8272791	Bracket, Element
10	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009080	Black Left
	W10009090	Black Right
	W10009040	White Left
	W10009050	White Right
2	9757609	Nameplate
3		Panel, Control
	9763290	Black
	9763289	White
	9763288	Silver
4		Switch, Infinite
	9758060	LF,RF
	3148951	LR,RR
5	8523265	Light, Ind. (2)
6	3196068	Lens, Light (2)
7		Knob, Infinite (4)
	9758129	Black
	9757132	White
8	8523280	Shield, Heat
9	3196166	Screw
10	9756999	Cover, Upper
12	9762967	Control, Range
13	3196178	Screw
14	9760080	Cnntr Cable, Flex
15		Receptacle
	9758889	White
	9758890	Black
	9758892	Stainless Steel
16	3400882	Screw
18		Breaker, 15 Amp
	9757601	White
	9757602	Black
	9757604	Stainless Steel
19	9756366	Cvr, Rear Console
20		Switch, Membrane
	9763583	White
	9763584	Black
21	9757358	Reflector, Light

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION
1	9760407	Brkt−Mntg,Dr Hnge
2	8273905	Support, Corner LR
3		Panel, Side (2)
	8053830	White−Textured
	8053832	Black−Textured
4	9761013	Latch, Door
5	3196961	Rod, Latch
6	9758228	Latch Asy, Rear
7	W10010350	Seal, Oven Flange
8	9757341	Element, Broil
9	9755770	Element, Bake
10	8522416	Seal, Oven Door
11	9758701	Spacer, Door
12	3196560	Screw
14	3196037	Foot, Front (2)
15		Frame, Front (Not Serviced)
16	8054068	Tray, Insulation
17	3196576	Clip, Panel (6)
18	9760314	Rail, Base (2)
19	9761935	Foot, Rear (2)
20	9761490	Insulation
21	3195813	Clip− Mounting
22	9758238	Retainer, Side (2)
23	8273902	Sensor, Oven
24	3195736	Support, Front (2)
25	3195987	Support, Corner RR
26	3196548	Fuse, Thermal
27	3196172	Screw
28	3186116	Support, Oven (2)
29	3186034	Bracket, Service
30	4449868	Block, Terminal
31	8274034	Back, Main
32	112432	Nut (3)
33	9761300	Vent Tube Asm
34	3196701	Light Socket Assy
35	311255	Bulb, Oven Light
36	9758283	Cover, Box
38	3196165	Screw
39	3196168	Screw
40	3196178	Screw
41	3196174	Screw
42	3196179	Screw
43	9755769	Tray−Bake,Hidden
44	W10031780	Screw
45	9755771	Cover, Tray
46	3400016	Screw
47	3196566	Screw
48	9757262	Switch − Door
49	9757239	Rod − Door Switch Rear Mount
50	9761301	Screen − Catalyst
51	9756350	Cord − Power
52	9759689	Card, Insulator
INSULATION		
	8272616	Insulation, Wrap
	9755772	Insulation, Back
	8272613	Insulation, Vent

DRAWER & BROILER PARTS

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	8522669	Spacer, Glide
3	9756711	Heat Shield, Drwr
4	9761030	Drawer, Storage
5	9758200	Bracket, Drawer(2)

Illus. No.	Part No.	DESCRIPTION
6		Rivet, Push (2)
	3196814	White
	3196813	Black
7		Drawer Front
	8053339	White
	8053341	Black
8		Rail, Drawer
	8274191	Right Hand
	8274190	Left Hand

Illus. No.	Part No.	DESCRIPTION
10	3196168	Screw
11	9755798	Panel, Stainless
12	9757237	Handle, Stainless
13	8274021	Rack, Partial
14	9781235	Clip
15	8274022	Rack, Insert

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)



Illus. No.	Part No.	DESCRIPTION
1		Trim, Top
	9762391	Black
	9761975	White
	9762394	Black Stainless
		Model
2	3196164	Screw
3		Handle, Door
	9761983	Black
	9761982	White
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	9761357	Retainer, Insltn
10	9761493	Hinge, Door (2)
11		Glass, Outer Door
	9762480	Black
	9762479	White
	9756435	Black Stainless
12		Trim, Side
	8523171	Black Left
	8523165	Black Right
	8523172	White Left
	8523166	White Right
13	3196160	Screw
14		Trim, Bottom
	8523177	Black
	8523175	White
	8523180	Black Stainless
		Model
15	W10031790	Screw
17	3196025	Clip, Door Glass
18	3196794	Bracket, Window(2)
19	3196165	Screw
21	9761517	Clip, Dr Mntg (2)
22	W10031780	Screw

OPTIONAL PARTS (NOT INCLUDED)

For Models: WERP4120SQ0, WERP4120SB0, WERP4120SS0
(Designer White) (Black) (Black Stainless)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass

ANTI−TIP KIT

W10017440	Anti−Tip Kit

WIRING HARNESS PARTS

9762815	Harness, Wire (Cooktop Left)
9762816	Harness, Wire (Cooktop Right)
9763631	Harness, Wire (Sensor/Dr Switch)
9763636	Harness, Wire (Main)
9757339	Harness Wire (Hidden Bake)
8523279	Wire, Ground
8524132	Shield, Wiring
3196173	Screw
3196154	Screw, Ground
9756779	Strain Relief